


SW2-CN For CNXX20/34 Non-spring Return Actuator SW2-CS For CSXX05/10/20 Spring Return Actuator

INSTALLATION INSTRUCTIONS

1 100 Vac, 5 (3) A M25331	2 M25332	3 (SW2-CS only) M25333
4 100 Vac, 5 (3) A M25331	5 24 V + 24 V ✓ M25335	6 M25336
7 6 Nm M25337	8 AS1 AS2 M25338	9 Setting AS1, AS2 10-15 M25339



Honeywell

Automation and Control Solutions

Honeywell International Inc.
1985 Douglas Drive North
Golden Valley, MN 55422

Honeywell (Tianjin) Limited
158, Nan Hai Road, TEDA
Tianjin, 300457, P.R.C.

Honeywell reserves the right to make changes
without further notice to any products herein.

EN1B-0270CH33 R1036A